

現行モデル

機種名	タイムカード	使用インクリボン
ER-60SU	ER-Sカード ER-Sカード/R ER-UDカード	ER-IR103 (黒)
ER-80SU・80SUW		
ER-110SU・110SUW・ 110SUW/AB・110SUW/USB		
ER-250S2	ER-Sカード ER-Sカード/R	ER-IR102 (黒・赤 2色)

旧モデル

機種名	タイムカード	使用インクリボン
ER-10S・20S	ER-Sカード ER-Sカード/R	ER-IR101 (黒)
ER-25S		ER-IR102 (黒・赤 2色)
ER-80S		ER-IR100 (黒)
ER-80S2・80S2C 80S2W・80S2CW		ER-IR103 (黒)
ER-110S5・110S5W・ 110S5C・110S5CW		ER-IR100 (黒)
ER-110S・110SII・110SIII・ 110SIIIW・110SIV		
ER-120S		ER-IR101 (黒)
ER-201S2/PC・231S2/PC タイムドック		
ER-210S・220S・240S		ER-IR102 (黒・赤 2色)
ER-250S		ER-IR101 (黒)
ER-270S		
ER-320S BSN		
ER-330S SRV		
ER-340S FLX		
ER-200S/PC・201S/PC・ 230S/PC・231S/PC・ 232S/PC		
ER-TC1000S TIME DOC 紙LAN		ER-UDカード
ER-180UD		